



## BANNER STANDS BANNER S10

**01** Unfold & assemble the 3-section pole and connect it to the foot.

O2 Connect the foot and pole assembly to the lower graphic profile.





O3 Pull up the graphic panel and bend the pole forward to connect the top of the pole to the slot on the upper graphic profile.

**04** Assembly is complete.

