


01 Insert the bottom of the pole into the hole on the back of the base.

BANNER STANDS SUPREME

02 Open the locking clamps on the telescopic pole.



03 Pull the graphic panel out of the base and insert the grey pastic clip on the top of the pole into the groove of the upper graphic profile.



04 Adjust the height of the telescopic pole according to the length of the graphic and close the locking clamps.

